


# GO! GO! heels

## PART LIST



## ADAPTER (Optional)

Once you run out of battery power you can always plug the adapter into an electrical wall socket for continuous use. Plug the other end into the unit.

**⚠ Note:** Before using the adapter, remove the batteries from the unit.

**⚠ Caution:** Do not immerse in water. Unplug immediately if the unit comes in contact with water.

## OPERATION

### Installing the Batteries:

Remove the battery compartment and insert 4 AA batteries; making sure they correspond to the polarities in the compartment. Once the batteries are situated, replace the battery compartment onto the GO! GO!™ Heels unit.

### Changing Accessories:

Remove the plastic cover and rotate the plastic railing clockwise. Once it reaches the end, pull the plastic railing out. The attachment can be removed by holding it on the sides and pulling it. Choose the appropriate attachment and place it on the pedicure set, making sure to align the hole at the bottom of the attachment with the metal pole on the pedicure set. Once the new attachment is situated, replace the plastic railing and turn it counterclockwise.

**⚠ Note:** Make sure the plastic railing is locked in before use.

## USAGE

GO! GO!™ Heels has two different speeds:

- 0 : Turns OFF the unit.
- Speed 1: Is used for areas that you want to treat gently.
- Speed 2: Is used for areas where you want to apply more pressure.

Switch to the appropriate speed to cater to your needs. Remove dead, dry, callused skin slowly, stopping to check the results from time to time.